RV 3 Mode 1

POSTREPLY Search this topic... Search

RV 3 Mode 1

QUOTE

by robbo » 06 Jul 2015, 01:12

Modes 1 to 3 are delay only. However, on Mode 1 I can hear what sounds like reverb coming through. Any RV 3 owners experience this ? Is this a fault or completely normal ? Modes 2 and 3 are delay only, no problem.

robbo

Posts: 22
Joined: 22 Dec 2011, 01:53

PM

Re: RV 3 Mode 1

QUOTE

by charmonder » 06 Jul 2015, 02:42

I never noticed it, I'll rig things up tomorrow and have a listen.

I have never used mode 3 for anything ever.

charmonder

Posts: 951
Joined: 04 Oct 2012, 17:45

PM

Re: RV 3 Mode 1

QUOTE

by visserman » 07 Jul 2015, 11:30

Mode 1 does not go that far, slabback maybe? So most of the settings in mode 1 will feel like some kind of "Echo" Mode 2 and 3 are the ones which have longer delay sounds.

My feel is that there is nothing wrong. Not sure what you are going for but if it is longer delay sounds you are looking for try mode 2 and 3.

By the way, the pedal does have artificial noises but your question was not about that. Most people will not notice, you will start to hear it when you use it in combination with microphone pre-amps (I tend to use RV 3 for vocals). The extra gain of the Microphone preamp will put everything under the microscope. RV2 and RV5 also suffer from this noise issue, it is all due to design, but again when used in combination with guitar amp you will not notice any of this.

visserman

BOSSAREA PLATINUM

Posts: 948
Joined: 09 Dec 2011, 15:46
Location: Leeds, West Yorkshire, England, UK

PM

Re: RV 3 Mode 1

QUOTE

by charmonder » 09 Jul 2015, 04:29

Rigged up the RV-3 today, just for kicks. It seems the mode1 does in fact have a reverby sound to it!

What I think is happening is the compander leaves a little white noise on the picking attack (to hear it use neck pick up, finger pick, tone knob all the way up for bright full sound, then listen for the bit of white noise on the attack), the mode 1 delay settings are short enough that that little bit of white noise piles up in feedback, so you get a little burst of white noise along with delay that makes

charmonder